

Technical Bulletin

Installation Tools / Supplies List Self-Adhesive Backed Material

- Scraper (to remove any tape or other surface imperfections)
- Mineral Spirits (for cleaning substrate)
- Step Ladder
- Slotted & Phillips Screw Drivers (to remove items such as frame)
- Auto Body Filler or Vinyl Spackle
- Medium & Fine Grit Sandpaper
- Drop Cloths (one to cut material on & one to keep installation area clean)
- Enamel Spray Paint (similar in color to substrate - lightly spot prime patched areas)
- Bucket (w/ clean water)
- Clean Sponge
- Pencil
- Tape Measure
- 4' Straight Edge or Level
- Razor Knife (w/ multiple blades)
- Pressurized Spray Bottle (available at hardware stores)
- Clear Dishwashing Detergent
- Flexible Wallcovering Smoother
- Soft Clean Cloths (many)
- 6" Broad Knife (for finish trimming)

Wallcovering Backed Material

Requires the above listed (EXCEPT: Mineral Spirits, Enamel Spray Paint, Auto Body Filler, Pressurized Spray Bottle, and Dishwashing Detergent) and the following:

- Double Cutting Tool (by Warner Tools or Advance Equipment Manufacturing Co.)
- Paint Roller (w/ 3/16" Nap Roller Cover for Primer and 1/2" Nap for Adhesive)
- Paint Pan (w/ Disposable Liners)
- Quality Acrylic Wallcovering Prep (Professional R-35 or similar for difficult to bond to surfaces)
- Joint Compound or similar Patching Compound
- Adhesive (Heavy Duty Clay or Clear, VOV for Impervious Surfaces)
- Chalk Line (use Light Color Chalk such as White or Yellow)
- Paint Brush
- Seam Roller
- Painter's Tape
- Level

